



Voyager – What You Need To Know


Power:

This vehicle is fitted with a second battery which will run the fridge and interior light when the vehicle is not running.

If you wish to save your battery the fridge can be manually turned off using the temperature control inside the fridge.

A mains power cable (normally located under passenger seat) is supplied for use on a campsite. Once the cable is plugged in you will be able to use the mains power points next to the fridge. Please follow the instructions below when connecting the mains power.

- Ensure that the power switch is off.
- Connect the cable to the campsite power point and the campervan
- Turn the power switch on o Use the “Test” button on the RCD to ensure the system is working correctly. Reset the RCD by pushing the lever back up
- The mains power is now ready to use.















The instructions for the control panel by the fridge are shown below.

| Symbol | Function | Description |
|--------|--|---|
| | Main 12v Power switch | This switch turns on (or off) the 12 volt power. As the power is turned on the Leisure battery is automatically selected and the LED display shows the battery voltage. The power is turned off automatically when the engine is started. See also 4.3 below. |
| | Auxiliary power switch | This switch turns the Awning, Entry or other Lighting on (or off). When the switch is on the LED will show Blue. |
| | Select LEISURE battery and display battery voltage | This switch is used to select the Leisure battery and to display the battery voltage level. Press once to select and display the voltage. This display will turn off automatically after 5 seconds. The LED next to the button will show that the battery has been selected. If the Leisure battery drops below 9V the LED will change to Red and an alarm will trigger to warn you that the battery is low. This alarm lasts for 1 minute and then the power will be switched off to protect the battery. See also 4.2.1 below. |
| | Select VEHICLE battery and display battery voltage | This switch is used to select the Vehicle battery and to display the battery voltage level. Press once to select and display the voltage. This display will turn off automatically after 5 seconds. The LED next to the button will show that the battery has been selected. If the Vehicle battery drops below 10.9V the LED will change to Red an alarm will trigger to warn you that the battery is low. This alarm lasts for 1 minute and then the battery selection will automatically switch over to the Leisure battery to protect the vehicle battery. See also 4.2.1 below. |

Bed:

-  Pull the red handles on the back of the chairs to fold the seats down.
-  Pull out the headrests to their furthest position. This will help make the bed more stable.
-  Place the white board on top of the folded seats. The board only fits one way round so make sure you've got it on the right way.
-  Place the square mattress section on top of the white board.
-  The remaining two mattress sections make up the second bed for the Voyager 4. The small flaps go towards the front of the vehicle.
-  A king size sheet is provided for the upper bed. And a standard double sheet for the lower bed.
-  Please ensure the floor area is clean before placing down the lower bed mattress sections

Curtains:

-  The thermo-insulated curtains use suction cups to stick to your windscreen and front windows.
-  Wetting the suction cups will help them to stay in place.
-  Clean window with glass cleaner (alcohol based).



Driving:

- The Ford Transit has six gears. Using sixth gear on the motorway will help you save fuel.
- The vehicle has double wing mirrors to give you a better view.
- The turning circle is larger than a normal car so please be careful when negotiating tight bends.
- This vehicle is fitted with an auto start/stop function. If you are sitting in traffic with the vehicle in neutral the engine will switch off. As soon as you put your foot on the clutch the engine will automatically restart.
- This vehicle has no fuel cap. The fuel flap is by the passenger door. You need to open the passenger door to open the fuel flap



IMPORTANT: YOUR VEHICLE IS 2.1 METRES TALL



Road Rules:

- Drive on the left in the UK and Ireland &
- Drive on the right in continental Europe
- Speed limits are in Miles per hour in the UK. In Europe and Ireland they are in KM/H
- You can use the AA website for more information per country.

What to do if you have an accident

If you and your Spaceship are involved in an accident, there are some basic things that will help you:

- Try to stay as calm as you can.
- Stop straight away and help anyone who's injured.
- Call an ambulance on 999 or EU 112 (or get someone to call an ambulance), if it's needed.
- Complete a European Accident Statement if the incident occurs outside of the UK. This document is required by law & both sides of the form should be completed & one part given to the third party driver.

Take clear images of:

- Damage caused to each of the vehicles including an image of the registration number
- If it is safe to do so, take photos of the scene of the accident to include road markings & any road signs plus the positions of the vehicles (or third party property) before they have been moved.
- If the third party is insured outside of the UK please try to take a clear photo of any insurance documents or "Green Card"
- Don't admit that the accident was your fault – it is important to look at all the available information following the stress of the accident. You may later find out other reasons why the accident occurred.